

#### **TOP AND CABINET PARTS**

For Model: LBR4121JQ2 (Designer White)

Illus. No.	Part No.	DESCRIPTION
1	LIT3956025	Literature Parts Installation
	LIT3955869 LIT3955901 LIT3956348 LIT8542049	Instructions Use & Care Guide Feature Sheet Energy Guide Wiring Diagram


#### **Following May Be Purchased**

# DO-IT-YOURSELF REPAIR MANUALS

LIT4313896 Manual, Washer 2 8274311 Top 3 62750 Spacer, Cabinet To Top (4) 63128 Cabinet 5 62780 Clip, Top & Cabinet 6 & Rear Panel (2) 7 3357011 Screw, 10-16 x 1/2 3356311 Screw & Washer, 8 Lid Switch (2) 11 3949239 Switch, Lid 13 3351355 Screw, Lid Hinge Mounting (4) 54584 Hinge, Lid (L.H.) 91770 Hinge, Lid (R.H.) 15 16 19119 Bumper, Lid Hinge 17 21258 Bearing, Lid 18 Hinge (2) 3361411 Lid 19 20 358684 Strike, Lid Switch 22 9724509 Bumper, Lid (2) 28 3390631 Screw, 10-16 x 3/8 90016 Clip, Harness 31 357213 Nut, Push-In (2) 32

#### **CONTROLS AND REAR PANEL PARTS**

For Model: LBR4121JQ2 (Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

#### **CONTROL AND REAR PANEL PARTS**

For Model: LBR4121JQ2 (Designer White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3976300	Washer, Water	9	3951166	Timer, Control	25	303294	Edge Protector
-		Inlet Hose (4)			(60 Hz.)	26		Hose-Corrugated
		(1–1/16 x 5/8)			(Motor Not A			Assembly
2 3	9740848	Screw, 8-18 x 1/2			Service Part)	27		Clamp, Hose
3		Hose, Water	10		Screw, Ground	28	8318201	Clip, Capacitor
		Inlet	11	90767	Screw, 8-18 x 3/8	29	3347812	Clip, Harness
	3949374	Blue Coupler	12		Switch, Water Level	30		Clamp, Hose
	3949375	Red Coupler	13	3948814	Bracket, Control	31		Clamp, Hose
4	3357027	Nozzle-Drain	14	661661	Cord, Power	32		Hose, Pump To Tub
		Hose			(Includes Item 15)	36	3400818	Screw, Timer
5		Hinge, Console (2)	15	3952821	,			Mounting
6		Panel, Rear			Power Cord	39		Panel, Console
7	62747	Pad, Rear Panel	16		Cap, End (L.H.)	44		Knob, Timer
8	3951609	Hose, Drain	17	3400073	•	45		Dial, Timer
		(4 ft.)			10-24 x 5/16	49	388326	Screw, 8–18 x 1.25
	661577		18	3955673	Valve, Water			(Panel to Top)
		(9 ft.)			Mixing	50		Screw, 10-16 x 3/8
		(Not Included)	19		Clamp, Hose	51		Cap, End (R.H.)
	3357090	•	20	661606	Capacitor,	52	3366913	Clamp, Drain
		Drain Hose			Motor Start			Hose
		(21 Inches.)	21		Clamp, Hose	54	3956511	
		(Not Included.)	22	62662	Hose, Vacuum			(For Detail See
				0=4=00	Break			Page 9 & 10)
			23		Clamp, Hose			
			24	3347034	Break, Vacuum			

## **AGITATOR, BASKET AND TUB PARTS**

For Model: LBR4121JQ2 (Designer White) 

# **AGITATOR, BASKET AND TUB PARTS**

For Model: LBR4121JQ2 (Designer White)


Illus. No.	Part No.	DESCRIPTION
1	3355758	Cap, Agitator
2	358237	
		(5/16-24 x 1)
4	3350151	Agitator
5	3360611	Tub Ring & Gasket
6	3359586	Gasket, Tub Ring
7	8519815	Clip, Balance
		Ring (8)
8	3956205	Balance Ring
10	3949550	Washer
12	21366	Nut, Spanner
13	3956206	Basket & Balance
		Ring
14	63125	Tub
15	389140	Block, Basket
		Drive
16	383727	Gasket, Centerpost
17	3363657	Hose, Pressure
		Switch

# BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS For Model: LBR4121JQ2

(Designer White)


		(D	esigner White)			
<b>6</b>	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
	1	388951	Brake & Drive Tube (Complete)	10	3357334	Screw, Gearcase To Base (3)
			(Refer to Page 11 For Further	11	62611	Plate, Motor Mount To Gearcase
1——	2	63292	Breakdown) Washer, Spin Tube Thrust	12 13		Grommet, Motor (4) Coupling, Motor
2	3		Ring, Spin Tube Support	14	2046532	And Isolation Coupling Shield, Motor
3	4 5 6	3951311	Ring, Retainer Clutch (Complete) Band & Lining,	16 17	3400516 3349637	Screw Retainer, Motor (2)
5	7		Clutch (Includes Illus. 7 & 8)	18 19		Shield, Tub To Motor Motor, Main
7 - 7 - 7	7 8		Cap, Clutch Spring (2) Spring, Clutch	20		Drive Switch, Main
	9	3360630	Gearcase (Complete)	21 22	62700	Drive Motor Retainer, Pump (2) Pump (Complete)
8 l 26 l			(Refer To Page 12 For Further Breakdown)	25 26	3387485 3355454	Screw, 10-16 x 5/8
9 10 11/12 13 14	16		19 17 25		18 25 17 20	5

#### **MACHINE BASE PARTS**



#### **WIRING HARNESS PARTS**

For Model: LBR4121JQ2 (Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

#### **WIRING HARNESS PARTS**

For Model: LBR4121JQ2 (Designer White)


Illus.	Part		Illus.	Part		Illus.	Part	
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
1	3349557	Clip, Harness	13	3348075	Block, Disconnect	23	3349494	Connector, Etc
2	388498	Clip, Harness			(Motor 3 Speed)	24		Connector, Relay
3		Clip, Harness			(Use Term. 94613			(Use Term.308569)
4	3352501		١		Or 94614.)	25		E.T.C. Control
5	90016	Clip, Harness	14	3347243		26	3948617	Connector (T.P.A.)
6		Clip, Harness	,_	00500	(Use Term. 352088)			(3–Circuit)
7	389379	Retainer,	15		Protector			(Lid Switch)
•	050000	(Suds Models)	16	717252	Connector			(Use Term. 3948619
8	352090	- ,			(2–Way)		0000050	OR 3948620.)
		Disconnect	17	207566	(Use Term.94614)	27	3360056	` ,
0	252000	(White)	''	307300	Plug, Terminal (4-Way)			(3–Circuit)
9	352069	Timer, Block Disconnect			(Power Cord)			(Pressure Switch)
		(Black)			(Use M3 Screws)			(Use Term.3948619 OR 3948620.)
10	62889	Receptacle,	18	3352944	Clip, Harness	28	3354925	Block, Connector
10	02000	Terminal	19		Block, Disconnect	20	3334323	(Cold Valve)
		(3–Way)	'	0000.20	(12–Way)			(Use Term.693217)
		(Lid Switch)			(Timer)	29	3354926	Block, Connector
		(Use Term.94613)			(Use Term. 94613)	~	000 1020	(Hot Valve)
		Or 94614.)	20	3347730				(Use Term.693217)
11	353424	Plug, Terminal			(6–Way)	30	3948615	
		(3-Way)			(Use Term. 94613)			(6–Circuit)
		(Power Cord)	21	388818	Plug, Terminal			(Temp. Switch)
		(Use Term.94613)			(12-Way)			(Use Term.3948619
12	62505	Block, Disconnect			(Use Term. 94613			OR 3948620.)
		(Motor 2 Speed)			Or 94614.)			
		(Use Term.352088)	22	3369366	Timer, Block			
					Disconnect			
					(Black) (Amp)			
					(Use Term.3369365)			
			l			l		

# FOR COMPLETE WIRING HARNESS REFER TO CONTROL AND REAR PANEL PARTS PAGE

WH2G

#### **BRAKE AND DRIVE TUBE PARTS**

For Model: LBR4121JQ2 (Designer White)



Illus.	Part						
No.	No.	DESCRIPTION					
1	388951	Brake And Drive Tube (Complete)					
2	62658	Ring, Thrust					
2 3 4	91939	Seal, Oil					
4	356427	Seal, Drive Tube					
5	356937	Spacer, Drive Tube					
6	64027	Tube, Basket Drive (Includes					
		Illus. 3, 4, 5 & 9)					
7	64035	Ring, Retaining					
8	64232	Brake Shoe					
9	62703	"T" Bearing,					
		Spin Tube					
10	62648	Cap, Brake					
11	62647	Spring (2) Spring, Brake					
12	62909	Sleeve, Brake					
	0_000	Spring					
13	63023	Cam, Brake					
		Release					
14	63022	Sleeve, Cam					
15	64194	Driver, Brake					
		Cam					
16	90368	Ring, Retaining					
FOLLOWING PARTS							

285208 Lubricant (Use Only In Brake Shoe Assembly On Roller & Pin)

**NOT ILLUSTRATED** 

1


### **GEARCASE PARTS**


For Model: LBR4121JQ2 (Designer White)

		(Designer white)			
;	=	<del></del>	٦	1	
-   '			<b></b>		
1		$\begin{pmatrix} 1 \\ 1 \end{pmatrix}$	1		
12		<b>\</b> /),	ı Illus.	Part	
; ¬,			ı No.	No.	DESCRIPTION
_ ! <b>\</b>	3		1 110.	140.	BECCIAII HOIL
,		1	I		
1 [			1	3360630	Gearcase
1 5			1	005000	(Complete)
1 ,		23	' 2 I 3	285202	Cover, Gearcase
, <i>f</i>	6		' 3 I	3349985	Seal, Gearcase Cover
' '		7 24	4	285195	Sealer, Gasket
, I	<u></u> <u></u>	/ <b>—</b> 24		200.00	(.20 Fl. Oz.) (6 ml)
	r — — — <del> </del>	1 /	I 5	63320	Pinion, Spin
1	, 8 <del></del> ♥	25	1		(Includes Illus. 25)
ı			1 6	356427	Seal, Spin
i I	9 🗐	26	· 		Pinion
	10 —	- CALLETTI THE PARTY OF THE PAR	7	389387	Shaft, Agitator
l	10		I 1 8	90369	(Complete) Ring, Retaining (2)
	9 —		9	62677	Retainer, Spring
		🔾 '	I 10	62676	Spring, Agitate
1	11		11	63273	Gear, Agitate
1			I		(Includes 15 and 29)
'	12		12	62619	Washer, Agitate
!	13			00500	Gear
			J 13	62580	Cam Follower
1	14		I . 14	62581	(Includes 14) Cam, Agitate
1			Ι '-	02301	(Includes 13)
1			15	285509	Shaft, Agitator
i			I		(Includes 11 and 29)
'	!	!	16	62618	Washer, Cam Thrust
			17	16018	Bearing, Thrust
J	ı		I 18	85529	Ball, Bearing
1	l <sub></sub>	·	I 19	389230	Bottom and Pinion, Gearcase
	15 _	27	l 21	285352	Seal, Thrust Plug
1		The state of the s	1 22	3351614	Screw, Gearcase
i	Profi		·		Cover, Mounting (8)
<u> </u>	16		1		(10-24 x 3/8)
!	16	28	23	3362552	Ring, Retaining
	29		J 24	285735	Washer Kit,
		i	I 25	62570	Thrust Gear, Spin
	8 — 8		I 25	388253	Neutral Assembly
147	└		1 27	3349296	Rack, Connecting
117		1	28	62621	Actuator, Shift
¦ 18		_ 19	. 29	388815	Washer,
.0	r / ( ( )		I		Intermediate
	100	www.	1		
1			1		
1			1		
i	21		I		
i					
!	' \ \\X9\m\\\\		1		
1	1 / 10/		1		
1		4	I		
1	L <del>_</del>	GC-215-C	I		
L			ı		

#### **WATER SYSTEM PARTS**

For Model: LBR4121JQ2 (Designer White)






WS400

Illus. No.	Part No.	DESCRIPTION
1	285442	Connector Kit, Plastic Drain Hose
2	285321	Sleeve Kit, (Contains 2 Sleeves)
3	370447	Clamp, Hose
4	16272	Connector, Straight
5	285320	Siphon Break Kit
6 7	65349 367031	(Not Included) Clamp, Hose Drain Protector (Not Included)

#### **MISCELLANEOUS PARTS**

For Model: LBR4121JQ2 (Designer White)



Illus. No.	Part No.	DESCRIPTION
1	3976263	Miscellaneous Parts Bag
2	3976300	Washer, Inlet Hose
3	3366913	(1-1/16 x 5/8) (4) Clamp, Hose
4		Nut, Lock (2)
5 7		(3/8–16) Foot, Front (2) Clamp, Hose

# **OPTIONAL PARTS (NOT INCLUDED)**

Illus. Part No. No. DESCRIPTION	Illus. Pa	art o. DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
PAINT, TOUCH-UP (1/2oz.)	OIL		SEA	LER	
72017 White	35	50572 Oil, Gearcase (16 Oz.)		285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)
PAINT, PRESSURIZED SPRAY (12 oz.)		(10 02.)	ACC	CESSOR	Y PARTS
350938 Primer, Gray 350930 White PAINT, BULK (1 qt.) 799344 White (Uncut)	LUBRIC 28	35208 Lubricant (Use Only in Brake Shoe Assembly On Roller and Pin)			Drain Protector Siphon Break Kit